

# HARMONY

SI DH 28 ..

71

1 / 4

(GB) Assembly instructions

(DE) Montageanleitung

(FR) Notice de montage

(NL) Handleiding voor de montage

(IT) Istruzioni di montaggio

(HU) Szerelési útmutató

(ES) Instrucciones de montaje

(PL) Instrukcja montażu

(CZ) Montá ní návod








(SK) Návod na montá

(HR) Monta e

(TR) Montaj talimat

(RO) Instrucțiuni de montaj

(RU) Инструкция по монтажу



# HARMONY

SI DH 28 ..

71

2 / 4

## Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Servizio • Servicio • Usluga • Сервисная Служба

Name • Nom • Naam • Nazwa  
Jméno • Názov • Név • Denumire  
Nombre • Ime • İsim • Название

Nr. • № • N° • Nummer • N • Sz • №


shop • geschäft • boutique • sklep • winkel • магазин  
negozi • bolt • tienda • obchod • dučkan • mağaza • magazin

## HARMONY

Typ • Type • Tip • Tipus • Тип






71






## SI DH 28..



Icon of a person holding a wrench.




X...






X...




X...



X...




X...



|        |  |  |
|--------|--|--|
| ART.:  | ABCD 03                                      | PP 03/03   |
| Typ:   | 000 X 000 X 000                              | 000 X 00 X 00 cm   |
| Farbe: | XXXXXXXXXXXX<br>XXXXXXXXXXXX<br>XXXXXXXXXXXX | Per la finitura del prodotto<br>negozio • bolt • tienda • obchod • dučkan • mağaza • magazin |

& QQJEV/0000000

1/2



## HARMONY

SI DH 28 ..

71

3 / 4

|     |          |    |
|-----|----------|----|
| C2  | fi 20    | x8 |
| J44 | 59x48x10 | x4 |
| S25 | 4x20     | x8 |

1

|     |        |    |
|-----|--------|----|
| S10 | 3.5x25 | x2 |
| G17 | M6x30  | x2 |

2

